



CNStream Developer Guide

Release 2020-04-16 (Version 4.4.0)

Apr 13, 2020



Table of Contents

Table of Contents	i
1 Copyright	1
2 CNStream Datatypes Reference	3
2.1 Data Source	3
2.1.1 DataSource	3
2.1.2 DataSourceParam	3
2.1.3 DecoderType	4
2.1.4 OutputType	5
2.1.5 SourceType	5
2.2 EventBus	6
2.2.1 Event	6
2.2.2 EventBus	6
2.2.3 EventHandleFlag	6
2.2.4 EventType	7
2.3 Frame	8
2.3.1 CNDataFormat	8
2.3.2 CNDataFrame	8
2.3.3 CNFrameFlag	11
2.3.4 CNFrameInfo	11
2.3.5 CNInferAttr	12
2.3.6 CNInferBoundingBox	12
2.3.7 CNInferFeature	13
2.3.8 CNInferObject	13
2.3.9 DevContext	15
2.3.10 ICNMediaImageMapper	16
2.3.11 IDataDeallocator	16
2.3.12 MemMapType	16
2.4 Inferencer	16
2.4.1 CNFrameInfoPtr	16
2.4.2 Inferencer	16
2.5 Module	17
2.5.1 Module	17
2.5.2 ModuleCreator	17
2.5.3 ModuleCreatorWorker	17
2.5.4 ModuleEx	17
2.5.5 ModuleFactory	17

2.5.6	ModuleParamSet	18
2.5.7	ParametersChecker	18
2.5.8	ParamRegister	18
2.6	Perf Calculator	18
2.6.1	PerfCalculator	18
2.6.2	PerfStats	18
2.7	Perf Manager	19
2.7.1	PerfInfo	19
2.7.2	PerfManager	19
2.8	Pipeline	20
2.8.1	CNModuleConfig	20
2.8.2	LinkStatus	21
2.8.3	Pipeline	22
2.8.4	StreamMsg	22
2.8.5	StreamMsgObserver	22
2.8.6	StreamMsgType	22
2.9	SyncMem	24
2.9.1	CNSyncedMemory	24
2.9.2	SyncedHead	24
2.10	Tracker	25
2.10.1	Tracker	25
3	CNStream API Reference	26
3.1	Data Source	26
3.1.1	CheckParamSet	26
3.1.2	Close	26
3.1.3	CreateSource	26
3.1.4	GetSourceParam	27
3.1.5	Open	27
3.2	Eventbus	27
3.2.1	AddBusWatch	27
3.2.2	BusWatcher	28
3.2.3	ClearAllWatchers	28
3.2.4	GetBusWatchers	28
3.2.5	IsRunning	28
3.2.6	PollEvent	28
3.2.7	PostEvent	28
3.3	Frame	29
3.3.1	AddAttribute	29
3.3.2	AddAttribute	29
3.3.3	AddExtraAttribute	29
3.3.4	AddExtraAttribute	29
3.3.5	AddFeature	30
3.3.6	CNGetPlanes	30
3.3.7	CopyToSharedMem	30
3.3.8	CopyToSyncMem	30
3.3.9	Create	30

3.3.10	GetAttribute	31
3.3.11	GetBytes	31
3.3.12	GetExtraAttribute	31
3.3.13	GetFeatures	31
3.3.14	GetMediaImage	31
3.3.15	GetPlanes	32
3.3.16	GetPlaneBytes	32
3.3.17	ImageBGR	32
3.3.18	~ICNMediaImageMapper	32
3.3.19	MmapSharedMem	32
3.3.20	ReleaseSharedMem	32
3.3.21	UnMapSharedMem	33
3.4	Inferencer	33
3.4.1	CheckParamSet	33
3.4.2	Close	33
3.4.3	Open	33
3.4.4	Process	34
3.5	Module	34
3.5.1	CheckParamSet	34
3.5.2	CheckPath	34
3.5.3	Close	34
3.5.4	Create	34
3.5.5	Create	35
3.5.6	CreateObject	35
3.5.7	ClearPerfManagers	35
3.5.8	DoProcess	35
3.5.9	GetModuleDesc	36
3.5.10	GetName	36
3.5.11	GetOutputFrame	36
3.5.12	GetParams	36
3.5.13	GetPathRelativeToTheJSONFile	36
3.5.14	GetPerfManager	37
3.5.15	GetRegistered	37
3.5.16	HasTransmit	37
3.5.17	Instance	37
3.5.18	IsNum	37
3.5.19	IsRegistered	38
3.5.20	Open	38
3.5.21	PostEvent	38
3.5.22	Process	38
3.5.23	Regist	39
3.5.24	Register	39
3.5.25	SetContainer	39
3.5.26	SetModuleDesc	39
3.5.27	SetPerfManagers	40
3.5.28	ShowPerfInfo	40
3.5.29	ShowPerfInfo	40

3.5.30	TransmitData	40
3.6	Per Calculator	40
3.6.1	CalcLatency	40
3.6.2	CalcThroughput	41
3.6.3	PrintLatency	41
3.6.4	PrintPerfStats	41
3.6.5	PrintThroughput	42
3.7	Perf Manager	42
3.7.1	CalculatePerfStats	42
3.7.2	CalculatePipelinePerfStats	42
3.7.3	Init	42
3.7.4	RecordPerfInfo	43
3.7.5	RegisterPerfType	43
3.7.6	SqlBeginTrans	43
3.7.7	SqlCommitTrans	43
3.7.8	Stop	43
3.8	Pipelines	43
3.8.1	AddModule	43
3.8.2	AddModuleConfig	44
3.8.3	BuildPipeline	44
3.8.4	BuildPipelineByJSONFile	44
3.8.5	CalculateModulePerfStats	45
3.8.6	CalculatePerfStats	45
3.8.7	CalculatePipelinePerfStats	45
3.8.8	Close	45
3.8.9	CreatePerfManager	45
3.8.10	GetEventBus	46
3.8.11	GetLinkIds	46
3.8.12	GetModule	46
3.8.13	GetModuleConfig	46
3.8.14	GetModuleParallelism	46
3.8.15	GetModuleParamSet	47
3.8.16	GetStreamMsgObserver	47
3.8.17	IsRunning	47
3.8.18	LinkModules	47
3.8.19	NotifyStreamMsg	48
3.8.20	Open	48
3.8.21	ParseByJSONFile	48
3.8.22	ParseByJSONStr	48
3.8.23	PerfSqlCommitLoop	48
3.8.24	Process	48
3.8.25	ProvideData	49
3.8.26	QueryLinkStatus	49
3.8.27	RegistIPCFrameDoneCallBack	49
3.8.28	SetModuleAttribute	49
3.8.29	SetStreamMsgObserver	50
3.8.30	Start	50

3.8.31	Stop	50
3.9	Syncmem	50
3.9.1	CNStreamFreeHost	50
3.9.2	CNStreamMallocHost	50
3.9.3	CNSyncedMemory	51
3.9.4	CNSyncedMemory	51
3.9.5	GetCpuData	51
3.9.6	GetHead	51
3.9.7	GetMluData	51
3.9.8	GetMluDdrChnId	51
3.9.9	GetMluDevId	52
3.9.10	GetMutableCpuData	52
3.9.11	GetMutableMluData	52
3.9.12	GetSize	52
3.9.13	SetCpuData	52
3.9.14	SetMluCpuData	52
3.9.15	SetMluData	53
3.9.16	SetMluDevContext	53
3.9.17	ToCpu	53
3.9.18	ToMlu	53
3.10	Tracker	53
3.10.1	CheckParamSet	53
3.10.2	Close	53
3.10.3	Open	54
3.10.4	Process	54
4	Release Notes	55
4.1	Release 2020-04-16 (Version 4.4.0)	55
4.1.1	API Updates	55
4.1.2	Doc Updates	55
4.2	Release 2020-02-24	56
4.2.1	API Updates	56
4.3	Release 2019-12-31	56
4.3.1	API Updates	56



1 Copyright

The Information in this guide and all other information contained in Cambricon Documentation Referenced in this guide is provided “AS IS.” Cambricon Makes no Warranties, Expressed, Implied, Statutory, or otherwise with respect to the information and expressly disclaims all implied warranties of noninfringement merchantability, title, noninfringement of intellectual property or fitness for a particular purpose. Notwithstanding any damages that customer might incur for any reason whatsoever, Cambricon’s aggregate and cumulative liability towards customer for the product described in this guide shall be limited in accordance with the Cambricon terms and conditions of sale for the product.

IN no event shall Cambricon be liable for any damages whatsoever (Including, without limitation, damages for loss of profits, business interruption, loss of information) arising out of the use of or inability to use this guide, even if Cambricon has been advised of the possibility of such damages.

Cambricon does not warrant the accuracy or completeness of the information, text, graphics, links or other items contained within this guide. Cambricon may make changes to this guide, or to the products described therein, at any time without notice, but makes no commitment to update this guide.

Performance tests and ratings are measured using specific chip systems and/or components. The results reflect the approximate performance of Cambricon products as measured by those tests. Any difference in system hardware or software design or configuration may affect actual performance. Cambricon makes no representation or warranty that the product described in this guide will be suitable for any specified use without further testing or modification. Testing of all parameters of each product is not necessarily performed by Cambricon. It is customer’s sole responsibility to ensure the product is suitable and fit for the application planned by customer and to do the necessary testing for the application in order to avoid a default of the application or the product.

Weaknesses in customer’s product designs may affect the quality and reliability of the Cambricon product and may result in additional or different conditions and/ or requirements beyond those contained in this guide. Cambricon does not accept any liability related to any default, damage, costs or problem which may be based on or attributable to: (i) the use of the Cambricon product in any manner that is contrary to this guide, or (ii) customer product designs.

This guide is copyrighted and is protected by worldwide copyright laws and treaty provisions. This guide may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without Cambricon’s prior written permission. Except as expressly provided herein, Cambricon and its suppliers do not grant any express or implied right to you under any patents, copyrights, trademarks, trade secret or any other intellectual property or proprietary right. Other than the right for customer to use the information in this guide with the product, no other license, either expressed or implied, is hereby granted by Cambricon under this guide.

1. COPYRIGHT

Cambricon and the Cambricon logo are trademarks and/or registered trademarks of Cambricon Corporation in the United States and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

Copyright © 2020 Cambricon Corporation. All rights reserved.



2 CNStream Datatypes Reference

CNStream data types support both on MLU270 and MLU220.

2.1 Data Source

2.1.1 DataSource

```
class cnstream::DataSource
```

The class for handling input data.

Inherits from SourceModule, `cnstream::ModuleCreator< DataSource >`

2.1.2 DataSourceParam

```
struct DataSourceParam {  
    SourceType source_type_ = SOURCE_RAW;  
    OutputType output_type_ = OUTPUT_CPU;  
    size_t interval_ = 1;  
    DecoderType decoder_type_ = DECODER_CPU;  
    bool reuse_cndec_buf = false;  
    int device_id_ = -1;  
    size_t chunk_size_ = 0;  
    size_t width_ = 0;  
    size_t height_ = 0;  
    bool interlaced_ = false;  
    size_t output_w = 0;  
    size_t output_h = 0;  
    uint32_t input_buf_number_ = 2;  
    uint32_t output_buf_number_ = 3;
```

```
};
```

```
};
```

```
struct cnstream::DataSourceParam
```

A structure for private usage.

Public Members

SourceType source_type_ = SOURCE_RAW

The demuxer type. The SOURCE_RAW value is set for debugging.

OutputType output_type_ = OUTPUT_CPU

Outputs data to CPU or MLU.

size_t interval_ = 1

Outputs image every interval frames.

DecoderType decoder_type_ = DECODER_CPU

The decoder type.

bool reuse_cndec_buf = false

Valid when DECODER_MLU is used.

int device_id_ = -1

The MLU device ID. To disable MLU, set the value to -1 .

size_t chunk_size_ = 0

Valid when SOURCE_RAW is used. For H264 and H265 only.

size_t width_ = 0

Valid when SOURCE_RAW is used. For H264 and H265 only.

size_t height_ = 0

Valid when SOURCE_RAW is used. For H264 and H265 only.

bool interlaced_ = false

Valid when SOURCE_RAW is used. For H264 and H265 only.

size_t output_w = 0

Valid for MLU100.

size_t output_h = 0

Valid for MLU100.

uint32_t input_buf_number_ = 2

Valid when decoder_type is set to DECODER_MLU.

uint32_t output_buf_number_ = 3

Valid when decoder_type is set to DECODER_MLU.

2.1.3 DecoderType

```
enum DecoderType {
```

```
    DECODER_CPU,
```

```
    DECODER_MLU
```

```
};
```

```
enum cnstream::DecoderType
```

The decoder type used in the source module.

Values:

```
DECODER_CPU
```

CPU decoder with FFmpeg.

```
DECODER_MLU
```

MLU decoder with CNCodec.

2.1.4 OutputType

```
enum OutputType {
```

```
    OUTPUT_CPU,
```

```
    OUTPUT_MLU
```

```
};
```

```
enum cnstream::OutputType
```

The storage type of the output frame data that are stored for modules on CPU or MLU.

Values:

```
OUTPUT_CPU
```

Outputs to CPU.

```
OUTPUT_MLU
```

Outputs to MLU.

2.1.5 SourceType

```
enum SourceType {
```

```
    SOURCE_RAW,
```

```
    SOURCE_FFmpeg
```

```
};
```

```
enum cnstream::SourceType
```

The type of stream or source to be processed.

Values:

```
SOURCE_RAW
```

Represents the raw stream. The source is sent for decoding directly.

```
SOURCE_FFmpeg
```

Represents the normal stream. The source is demuxed with FFmpeg before send for decoding.

2.2 EventBus

2.2.1 Event

```
struct Event {  
    EventType type;  
    std::string message;  
    const Module *module;  
    std::thread::id thread_id;  
};
```

```
struct cnstream::Event
```

The structure holding the event information.

Public Members

`EventType` `type`

The event type.

`std::string` `message`

Additional event messages.

`const Module *` `module`

The module that posts this event.

`std::thread::id` `thread_id`

The thread ID from which the event is posted.

2.2.2 EventBus

```
class cnstream::EventBus
```

The event bus that transmits events from modules to a pipeline.

2.2.3 EventHandleFlag

```
enum EventHandleFlag {  
    EVENT_HANDLE_NULL,  
    EVENT_HANDLE_INTERCEPTION,  
    EVENT_HANDLE_SYNCED,  
    EVENT_HANDLE_STOP  
};
```

```
enum cnstream::EventHandleFlag
    Flags to specify the way in which bus watcher handled one event.
    Values:
    EVENT_HANDLE_NULL
        Event is not handled.
    EVENT_HANDLE_INTERCEPTION
        Watcher is informed and intercepts the event.
    EVENT_HANDLE_SYNCED
        Watcher is informed and informs other watchers.
    EVENT_HANDLE_STOP
        Stops a poll event.
```

2.2.4 EventType

```
enum EventType {
    EVENT_INVALID,
    EVENT_ERROR,
    EVENT_WARNING,
    EVENT_EOS,
    EVENT_STOP,
    EVENT_TYPE_END
};
enum cnstream::EventType
    Flags to specify how bus watchers handle a single event.
    Values:
    EVENT_INVALID
        An invalid event type.
    EVENT_ERROR
        An error event.
    EVENT_WARNING
        A warning event.
    EVENT_EOS
        An EOS (End of Stream) event.
    EVENT_STOP
        Stops an event that is called by an application.
    EVENT_TYPE_END
        Reserved for your custom events.
```

2.3 Frame

2.3.1 CNDataFormat

```
enum CNDataFormat {  
    CN_INVALID = -1,  
    CN_PIXEL_FORMAT_YUV420_NV21 = 0,  
    CN_PIXEL_FORMAT_YUV420_NV12,  
    CN_PIXEL_FORMAT_BGR24,  
    CN_PIXEL_FORMAT_RGB24  
};
```

`enum cnstream::CNDataFormat`

An enumerated type that is used to identify the pixel format of the data in `CNDataFrame`.

Values:

`CN_INVALID = -1`

This frame is invalid.

`CN_PIXEL_FORMAT_YUV420_NV21 = 0`

This frame is in the YUV420SP(NV21) format.

`CN_PIXEL_FORMAT_YUV420_NV12`

This frame is in the YUV420sp(NV12) format.

`CN_PIXEL_FORMAT_BGR24`

This frame is in the BGR24 format.

`CN_PIXEL_FORMAT_RGB24`

This frame is in the RGB24 format.

2.3.2 CNDataFrame

```
typedef struct {  
    std::string stream_id;  
    size_t flags = 0;  
    int64_t frame_id;  
    int64_t timestamp;  
} CNDataFrame;
```

`struct cnstream::CNDataFrame`

The structure holding a data frame and the frame description.

Public Functions

`int GetPlanes() const`

Gets plane count for a specified frame.

Return Returns the plane count of this frame.

`size_t GetPlaneBytes(int plane_idx) const`

Gets the number of bytes in a specified plane.

Return Returns the number of bytes in the plane.

Parameters

- `plane_idx`: The index of the plane. The index increments from 0.

`size_t GetBytes() const`

Gets the number of bytes in a frame.

Return Returns the number of bytes in a frame.

`void CopyToSyncMem()`

Synchronizes the source-data to [CNSyncedMemory](#).

`void MmapSharedMem(MemMapType type)`

Map shared memory, for multi-process case.

Return void.

Parameters

- `memory`: map/shared type.

`void UnMapSharedMem(MemMapType type)`

Unmap shared memory, for multi-process case.

Return void.

Parameters

- `memory`: map/shared type.

`void CopyToSharedMem(MemMapType type)`

Copy source-data to shared memory, for multi-process case.

Return void.

Parameters

- `memory`: map/shared type.

`void ReleaseSharedMem(MemMapType type)`

Release shared memory, for multi-process case.

Return void.

Parameters

- `memory`: map/shared type.

`cv::Mat *ImageBGR()`

Converts data from RGB to BGR. Called after [CopyToSyncMem\(\)](#) is invoked.

If data is not RGB image but BGR, YUV420NV12 or YUV420NV21 image, its color mode will not be converted.

Return Returns data with opencv mat type.

Public Members

`std::string stream_id`

The data stream aliases where this frame is located to.

`size_t flags = 0`

The mask for this frame, `CNFrameFlag`.

`int64_t frame_id`

The frame index that incremented from 0.

`int64_t timestamp`

The time stamp of this frame.

`CNDataFormat fmt`

The format of the frame.

The source data information. You need to set the information before calling `CopyToSyncMem()`.

`int width`

The width of the frame.

`int height`

The height of the frame.

`int stride[CN_MAX_PLANES]`

The strides of the frame.

`DevContext ctx`

The device context of this frame.

`void *ptr_mlu[CN_MAX_PLANES]`

The MLU data addresses for planes.

`void *ptr_cpu[CN_MAX_PLANES]`

The CPU data addresses for planes.

`void *mlu_mem_handle = nullptr`

The MLU memory handle for mlu data.

`std::shared_ptr<IDataDeallocator> deAllocator_ = nullptr`

The dedicated deallocator for CNDecoder Buffer.

`std::shared_ptr<CNMediaImageMapper> mapper_ = nullptr`

The dedicated Mapper for M220 CNDecoder.

`void *cpu_data = nullptr`

CPU data pointer. You need to allocate it by calling `CNStreamMallocHost()`.

`void *mlu_data = nullptr`

A pointer to the MLU data.

`std::shared_ptr<CNSyncedMemory> data[CN_MAX_PLANES]`
 Sync data helper.

2.3.3 CNFrameFlag

```
enum CNFrameFlag {
    CN_FRAME_FLAG_EOS = 1 << 0
};
```

`enum cnstream::CNFrameFlag`

An enumerated type that specifies the mask of `CNDataFrame`.

Values:

```
CN_FRAME_FLAG_EOS = 1 << 0
    Identifies the end of data stream.
```

2.3.4 CNFrameInfo

```
typedef struct {
    static std::shared_ptr<CNFrameInfo> Create(const std::string& stream_id,
        bool eos = false);

    uint32_t channel_idx = INVALID_STREAM_IDX;

    CNDataFrame frame;

    std::vector<std::shared_ptr<CNInferObject>> objs;

    ~CNFrameInfo();

private:
    CNFrameInfo() {}

    DISABLE_COPY_AND_ASSIGN(CNFrameInfo);

    static std::mutex mutex_;

    static std::map<std::string, int> stream_count_map_;

public:
    static int parallelism_;
} CNFrameInfo;
```

`struct cnstream::CNFrameInfo`

A structure holding the information of a frame.

Public Members

```
uint32_t channel_idx = INVALID_STREAM_IDX
    The index of the channel, stream_index.
```

`CNDataFrame frame`

The data of the frame.

`ThreadSafeVector<std::shared_ptr<CNInferObject>> objs`

Structured information of the objects for this frame.

Public Static Functions

`static std::shared_ptr<CNFrameInfo> Create(const std::string &stream_id, bool eos = false)`

Creates a `CNFrameInfo` instance.

Return Returns `shared_ptr` of `CNFrameInfo` if this function has run successfully. Otherwise, returns `NULL`.

Parameters

- `stream_id`: The data stream alias. Identifies which data stream the frame data comes from.
- `eos`: If true, `CNDataFrame::flags` will be set to `CN_FRAME_FLAG_EOS`. Then, the modules do not have permission to process this frame. This frame should be handed over to the pipeline for processing.

2.3.5 CNInferAttr

```
typedef struct {
    int id = -1;
    int value = -1;
    float score = 0;
} CNInferAttr;
```

`struct cnstream::CNInferAttr`

A structure holding the classification properties of an object.

Public Members

`int id = -1`

The unique ID of the classification. The value -1 is invalid.

`int value = -1`

The label value of the classification.

`float score = 0`

The label score of the classification.

2.3.6 CNInferBoundingBox

```
typedef struct {
```

```

    float x, y, w, h;
} CNInferBoundingBox;

```

```
struct cnstream::CNInferBoundingBox
```

A structure holding the bounding box for detection information of an object. Normalized coordinates.

2.3.7 CNInferFeature

```
typedef std::vector<float> cnstream::CNInferFeature
```

The feature value for one object.

2.3.8 CNInferObject

```

typedef struct {
    public:
        std::string id;
        std::string track_id;
        float score;
        CNInferBoundingBox bbox;
        void* user_data_ = nullptr;
    private:
        std::map<std::string, CNInferAttr> attributes_;
        std::map<std::string, std::string> extra_attributes_;
        std::vector<CNInferFeature> features_;
        std::mutex attribute_mutex_;
        std::mutex feature_mutex_;
} CNInferObject;

```

```
struct cnstream::CNInferObject
```

A structure holding the information for an object.

Public Functions

```
bool AddAttribute(const std::string &key, const CNInferAttr &value)
```

Adds the key of an attribute to a specified object.

Return Returns true if the attribute has been added successfully. Returns false if the attribute already exists.

Note This is a thread-safe function.

Parameters

- **key**: The Key of the attribute you want to add to. See [GetAttribute\(\)](#).

- `value`: The value of the attribute.

`bool AddAttribute(const std::pair<std::string, CNInferAttr> &attribute)`

Adds the key pairs of an attribute to a specified object.

Return Returns true if the attribute has been added successfully. Returns false if the attribute already exists.

Note This is a thread-safe function.

Parameters

- `attribute`: The attribute pair (key, value) to be added.

`CNInferAttr GetAttribute(const std::string &key)`

Gets an attribute by key.

Return Returns the attribute key. If the attribute does not exist, `CNInferAttr::id` will be set to -1.

Note This is a thread-safe function.

Parameters

- `key`: The key of an attribute you want to query. See [AddAttribute\(\)](#).

`bool AddExtraAttribute(const std::string &key, const std::string &value)`

Adds the key of the extended attribute to a specified object.

Return Returns true if the attribute has been added successfully. Returns false if the attribute already exists in the object.

Note This is a thread-safe function.

Parameters

- `key`: The key of an attribute. You can get this attribute by key. See [GetExtraAttribute\(\)](#).
- `value`: The value of the attribute.

`bool AddExtraAttribute(const std::vector<std::pair<std::string, std::string>> &attributes)`

Adds the key pairs of the extended attributes to a specified object.

Return Returns true if the attribute has been added successfully. Returns false if the attribute already exists.

Note This is a thread-safe function.

Parameters

- `attributes`: Attributes to be added.

`std::string GetExtraAttribute(const std::string &key)`

Gets the extended attribute by key.

Return Returns the attribute that is identified by the key. If the attribute does not exist, returns NULL.

Note This is a thread-safe function.

Parameters

- `key`: The key of an identified attribute. See [AddExtraAttribute\(\)](#).

`void AddFeature(const CNInferFeature &features)`

Adds the feature value to a specified object.

Return Void.

Note This is a thread-safe function.

Parameters

- `features`: The feature value you want to add to.

`std::vector<CNInferFeature> GetFeatures()`

Gets the features of an object.

Return Returns the features of an object.

Note This is a thread-safe function.

Public Members

`std::string id`

The ID of the classification. (label value).

`std::string track_id`

The tracking result.

`float score`

The label score.

`CNInferBoundingBox bbox`

The object normalized coordinates.

`void *user_data_ = nullptr`

User data. User can store their own data here.

2.3.9 DevContext

typedef struct {

DevType dev_type = INVALID;

int dev_id = 0;

int ddr_channel = 0

} DevContext;

`struct cnstream::DevContext`

Identifies if the `CNDataFrame` data is allocated by CPU or MLU.

Public Members

`cnstream::DevContext::DevType dev_type = INVALID`

Device type.

`int dev_id = 0`

Ordinal device ID.

`int ddr_channel = 0`

Ordinal channel ID for MLU. The value should be in the range [0, 4).

2.3.10 ICNMediaImageMapper

`class cnstream::ICNMediaImageMapper`
`ICNMediaImageMapper` is an abstract class.

2.3.11 IDataDeallocator

`class cnstream::IDataDeallocator`
 Dedicated deallocator the CNDecoder buffer.

2.3.12 MemMapType

```
enum MemMapType {
    MEMMAP_INVALID = 0,
    MEMMAP_CPU = 1,
    MEMMAP_MLU = 2
};
```

`enum cnstream::MemMapType`
 Identifies memory shared type for multi-process.

Values:

`MEMMAP_INVALID = 0`
 Invalid memory shared type.

`MEMMAP_CPU = 1`
 cpu memory shared type.

`MEMMAP_MLU = 2`
 mlu memory shared type.

2.4 Inferencer

2.4.1 CNFrameInfoPtr

`typedef std::shared_ptr<cnstream::CNFrameInfo> cnstream::CNFrameInfoPtr`
 Constructs a pointer to `CNFrameInfo`.
 Pointer for frame info.

2.4.2 Inferencer

`class cnstream::Inferencer`
`Inferencer` is a module for running offline model inference.

The input could come from Decoder or other plugins, in MLU memory or CPU memory. Also, If the `preproc_name` parameter is set to `PreprocCpu` in the Open function or configuration file, CPU is used for image preprocessing. Otherwise, if the `preproc_name` parameter is not set, MLU is used for image preprocessing. The image preprocessing includes data shape resizing and color space conversion. Afterwards, you can infer with offline model loading from the model path.

Inherits from `cnstream::Module`, `cnstream::ModuleCreator< Inferencer >`

2.5 Module

2.5.1 Module

```
class cnstream::Module
    Module virtual base class.
```

`Module` is the parent class of all modules. A module should have configurable number of upstream links and downstream links. Some modules are already constructed with a framework, such as source, inferencer, and so on. You can also design your own modules.

Subclassed by `cnstream::Inferencer`, `cnstream::ModuleEx`, `cnstream::Pipeline`, `cnstream::Tracker`

2.5.2 ModuleCreator

```
template <typename T>
class cnstream::ModuleCreator
    ModuleCreator A concrete ModuleClass needs to inherit ModuleCreator to enable reflection mechanism. ModuleCreator provides CreateFunction, and registers ModuleClassName and CreateFunction to ModuleFactory().
```

2.5.3 ModuleCreatorWorker

```
class cnstream::ModuleCreatorWorker
    ModuleCreatorWorker, a dynamic-creator helper.
```

2.5.4 ModuleEx

```
class cnstream::ModuleEx
    Inherits from cnstream::Module
```

2.5.5 ModuleFactory

```
class cnstream::ModuleFactory
    ModuleCreator, ModuleFactory, and ModuleCreatorWorker: Implements reflection mechanism to create a module instance dynamically with the ModuleClassName and moduleName
```

parameters. See ActorFactory&DynamicCreator in <https://github.com/Bwar/Nebula> (under Apache2.0 license)

`ModuleFactory` Provides functions to create instances with the `ModuleClassName` and `moduleName` parameters.

2.5.6 ModuleParamSet

```
typedef std::unordered_map<std::string, std::string> cnstream::ModuleParamSet
```

`Module` parameter set.

2.5.7 ParametersChecker

```
class cnstream::ParametersChecker
```

Checks the module parameters.

2.5.8 ParamRegister

```
class cnstream::Module::ParamRegister
```

`ParamRegister`.

Each module registers its own parameters and descriptions. CNStream Inspect tool uses this class to detect parameters of each module.

2.6 Perf Calculator

2.6.1 PerfCalculator

```
class cnstream::PerfCalculator
```

`PerfCalculator` class is for calculating performance statistics.

Reads useful data from database and then it could calculate performance statistics like latency and throughput.

2.6.2 PerfStats

```
typedef struct {  
    size_t latency_avg;  
    size_t latency_max;  
    size_t frame_cnt;  
    double fps;  
} PerfStats;
```



```
struct cnstream::PerfStats
```

The basic data structure of performance statistics, including latency, frame count and throughout.

2.7 Perf Manager

2.7.1 PerfInfo

```
struct PerfInfo {  
    bool is_finished;  
    std::string perf_type;  
    std::string module_name;  
    int64_t pts;  
    size_t timestamp;  
};
```

```
struct cnstream::PerfInfo
```

The basic data structure of measuring performance.

Records [PerfInfo](#) at start time point and end time point.

Public Members

`std::string perf_type`
If it is true means start time, otherwise end time.

`std::string module_name`
The perf type.

`int64_t pts`
The module name.

`size_t timestamp`
The pts of each data frame.

2.7.2 PerfManager

```
class cnstream::PerfManager
```

[PerfManager](#) class.

Records [PerfInfo](#) and calculates modules and pipeline performance statistics.

2.8 Pipeline

2.8.1 CNModuleConfig

```
typedef struct {
    std::string name;
    ModuleParamSet parameters;
    int parallelism;
    int maxInputQueueSize;
    std::string className;
    std::vector<std::string> next;
    void ParseByJSONStr(const std::string& jstr) noexcept(false);
    void ParseByJSONFile(const std::string& jfname) noexcept(false);
} CNModuleConfig;
```

`struct cnstream::CNModuleConfig`
The configuration parameters of a module.

You can use *CNModuleConfig* to add modules in a pipeline. The module configuration can be in JSON file.

```
"name(CNModuleConfig::name)": {
  custom_params(CNModuleConfig::parameters): {
    "key0": "value",
    "key1": "value",
    ...
  }
  "parallelism(CNModuleConfig::parallelism)": 3,
  "max_input_queue_size(CNModuleConfig::maxInputQueueSize)": 20,
  "class_name(CNModuleConfig::className)": "Inferencer",
  "next_modules": ["module0(CNModuleConfig::name)", "module1(CNModuleConfig::name)", ...],
}
```

See `Pipeline::AddModuleConfig`.

Public Functions

`bool ParseByJSONStr(const std::string &jstr)`

Parses members from JSON string except `CNModuleConfig::name`.

Return Returns true if the JSON file has been parsed successfully. Otherwise, returns false.

`bool ParseByJSONFile(const std::string &jfname)`

Parses members from JSON file except `CNModuleConfig::name`.

Return Returns true if the JSON file has been parsed successfully. Otherwise, returns false.

Public Members

std::string name

The name of the module.

ModuleParamSet parameters

The key-value pairs. The pipeline passes this value to the `CNModuleConfig::name` module.

int parallelism

Module parallelism. It is equal to module thread number and the data queue for input data.

int maxInputQueueSize

The maximum size of the input data queues.

std::string className

The class name of the module.

std::vector<std::string> next

The name of the downstream modules.

bool showPerfInfo

Whether to show performance information or not.

2.8.2 LinkStatus

```
typedef struct {
```

```
    bool stopped;
```

```
    std::vector<uint32_t> cache_size;
```

```
} LinkStatus;
```

```
struct cnstream::LinkStatus
```

The link status between modules.

Public Members

bool stopped

Whether the data transmissions between the modules are stopped.

std::vector<uint32_t> cache_size

The size of each queue that is used to cache data between modules.

2.8.3 Pipeline

`class cnstream::Pipeline`

The manager of the modules. Manages data transmission between modules, and controls message delivery.

Inherits from `cnstream::Module`

2.8.4 StreamMsg

```
typedef struct {
    StreamMsgType type;
    int32_t chn_idx;
    std::string stream_id = "" ;
} StreamMsg;
```

`struct cnstream::StreamMsg`

Specifies a stream message.

See [StreamMsgType](#).

Public Members

[StreamMsgType](#) type

The type of a message.

`int32_t chn_idx`

The index of a stream channel that incremented from 0.

`std::string stream_id = ""`

Stream ID. You can set in [CNDataFrame::stream_id](#).

2.8.5 StreamMsgObserver

`class cnstream::StreamMsgObserver`

Stream message observer.

Receives stream messages from a pipeline. To receive stream messages from the pipeline, you can define a class to inherit the [StreamMsgObserver](#) class and call the `Update` function. The observer instance are bounded to the pipeline using the [Pipeline::SetStreamMsgObserver](#) function .

See [Pipeline::SetStreamMsgObserver](#) [StreamMsg](#) [StreamMsgType](#).

2.8.6 StreamMsgType

```
enum StreamMsgType {
```

```
EOS_MSG = 0,  
ERROR_MSG,  
USER_MSG0 = 32,  
USER_MSG1,  
USER_MSG2,  
USER_MSG3,  
USER_MSG4,  
USER_MSG5,  
USER_MSG6,  
USER_MSG7,  
USER_MSG8,  
USER_MSG9
```

```
};
```

```
enum cnstream::StreamMsgType  
Data stream message type.
```

Values:

EOS_MSG = 0

The end of a stream message. The stream has received EOS message in all modules.

ERROR_MSG

An error message. The stream process has failed in one of the modules.

USER_MSG0 = 32

Reserved message. You can define your own messages.

USER_MSG1

Reserved message. You can define your own messages.

USER_MSG2

Reserved message. You can define your own messages.

USER_MSG3

Reserved message. You can define your own messages.

USER_MSG4

Reserved message. You can define your own messages.

USER_MSG5

Reserved message. You can define your own messages.

USER_MSG6

Reserved message. You can define your own messages.

USER_MSG7

Reserved message. You can define your own messages.

`USER_MSG8`

Reserved message. You can define your own messages.

`USER_MSG9`

Reserved message. You can define your own messages.

2.9 SyncMem

2.9.1 CNSyncedMemory

```
class cnstream::CNSyncedMemory
```

Synchronizes memory between CPU and MLU.

If the data on MLU is the latest, the data on CPU should be synchronized before processing the data on CPU. Vice versa, if the data on CPU is the latest, the data on MLU should be synchronized before processing the data on MLU.

Note `CNSyncedMemory::Head()` always returns `CNSyncedMemory::UNINITIALIZED` when memory size is 0.

2.9.2 SyncedHead

```
enum SyncedHead {
```

```
    UNINITIALIZED,
```

```
    HEAD_AT_CPU,
```

```
    HEAD_AT_MLU,
```

```
    SYNCED
```

```
};
```

```
enum cnstream::CNSyncedMemory::SyncedHead
```

Synchronized head.

Values:

`UNINITIALIZED`

The memory has not been allocated.

`HEAD_AT_CPU`

The data has been updated to CPU but has not been synchronized to MLU yet.

`HEAD_AT_MLU`

The data has been updated to MLU but has not been synchronized to CPU yet.

`SYNCED`

The data has been synchronized to both CPU and MLU.

2.10 Tracker

2.10.1 Tracker

`class cnstream::Tracker`

`Tracker` is a module for realtime tracking. It would be MLU feature extracting if the model path provided. Otherwise, it would be done on CPU.

Inherits from `cnstream::Module`, `cnstream::ModuleCreator< Tracker >`



3 CNStream API Reference

CNStream APIs support both on MLU270 and MLU220.

3.1 Data Source

3.1.1 CheckParamSet

`bool cnstream::DataSource::CheckParamSet(const ModuleParamSet ¶mSet) const`
Checks parameters for a module.

Return Returns true if this function has run successfully. Otherwise, returns false.

Parameters

- `paramSet`: Parameters for this module.

3.1.2 Close

`void cnstream::DataSource::Close()`
Called by pipeline when the pipeline is stopped.

3.1.3 CreateSource

```
std::shared_ptr<cnstream::SourceHandler> cnstream::DataSource::CreateSource(const
                                                                    std::string
                                                                    &stream_id,
                                                                    const
                                                                    std::string
                                                                    &filename,
                                                                    int fram-
                                                                    erate,
                                                                    bool
                                                                    loop =
                                                                    false)
```

Adds one stream to `DataSource` module. This function should be called after the pipeline has been started.

Return Returns the source handler instance.

Parameters

- `stream_id[in]`: The unique stream identifier.

- `filename[in]`: The source path that supports local-file-path, rtsp-url, jpg-sequences, and so on.
- `framerate[in]`: The input frequency of the source data.
- `loop[in]`: Whether to reload source when EOF is reached.

3.1.4 GetSourceParam

`DataSourceParam cnstream::DataSource::GetSourceParam() const`

Gets module parameters. This function should be called after `Open()` has been invoked.

3.1.5 Open

`bool cnstream::DataSource::Open(ModuleParamSet paramSet)`

Called by pipeline when the pipeline is started.

Return Returns true if `paramSet` are supported and valid. Otherwise, returns false.

Parameters

- `paramSet`:
 - `source_type`: Required. The demuxer type. Supported values are `raw` and `ffmpeg`.
 - `output_type`: Required. The output type. Supported values are `mlu` and `cpu`.
 - `interval`: Optional. The interval during which the data is handled.
 - `decoder_type`: Required. The decoder type. Supported values are `mlu` and `cpu`.
 - `reuse_cndec_buf`: Optional. This parameter should be set when MLU decoder is used. Supported values are `true` and `false`.
 - `device_id`: Required when MLU is used. Set the value to -1 for CPU. Set the value for MLU in the range 0 - N.
 - `chunk_size`: Required when `source_type` is set to `raw`.
 - `width`: Required when `source_type` is set to `raw`.
 - `height`: Required when `source_type` is set to `raw`.
 - `interlaced`: Required when `source_type` is set to `raw`.
 - `input_buf_number`: Optional. The input buffer number.
 - `output_buf_number`: Optional. The output buffer number.

3.2 Eventbus

3.2.1 AddBusWatch

`uint32_t cnstream::EventBus::AddBusWatch(BusWatcher func, Module *watch_module)`

Adds the watcher to the event bus.

Return The number of bus watchers that have been added to this event bus.

Parameters

- `func`: The bus watcher to be added.
- `watch_module`: The module that adds this bus watcher.

3.2.2 BusWatcher

```
typedef std::function<EventHandleFlag(const Event&, Module *)> cnstream::BusWatcher
```

The bus watcher function.

Return Returns the flag that specifies how the event is handled.

Parameters

- `event`: The event polled from the event bus.
- `module`: The module that is watching.

3.2.3 ClearAllWatchers

```
void cnstream::EventBus::ClearAllWatchers()
```

Removes all bus watchers.

3.2.4 GetBusWatchers

```
const std::list<std::pair<BusWatcher, Module *>> &cnstream::EventBus::GetBusWatchers() const
```

Gets all bus watchers from the event bus.

Return A list with pairs of bus watcher and module.

3.2.5 IsRunning

```
bool cnstream::EventBus::IsRunning() const
```

Checks if the event bus is running.

Return Returns true if the event bus is running. Otherwise, returns false.

3.2.6 PollEvent

```
Event cnstream::EventBus::PollEvent()
```

Polls an event from a bus [block].

Note This function is blocked until an event or a bus is stopped.

3.2.7 PostEvent

```
bool cnstream::EventBus::PostEvent(Event event)
```

Posts an event to a bus.

Return Returns true if this function has run successfully.

Parameters

- `event`: The event to be posted.

3.3 Frame

3.3.1 AddAttribute

```
bool cnstream::CNInferObject::AddAttribute(const std::pair<std::string, CNInferAttr>
                                           &attribute)
```

Adds the key pairs of an attribute to a specified object.

Return Returns true if the attribute has been added successfully. Returns false if the attribute already exists.

Note This is a thread-safe function.

Parameters

- `attribute`: The attribute pair (key, value) to be added.

3.3.2 AddAttribute

```
bool cnstream::CNInferObject::AddAttribute(const std::string &key, const CNInferAttr
                                           &value)
```

Adds the key of an attribute to a specified object.

Return Returns true if the attribute has been added successfully. Returns false if the attribute already exists.

Note This is a thread-safe function.

Parameters

- `key`: The Key of the attribute you want to add to. See [GetAttribute\(\)](#).
- `value`: The value of the attribute.

3.3.3 AddExtraAttribute

```
bool cnstream::CNInferObject::AddExtraAttribute(const std::string &key, const std::string
                                                &value)
```

Adds the key of the extended attribute to a specified object.

Return Returns true if the attribute has been added successfully. Returns false if the attribute already exists in the object.

Note This is a thread-safe function.

Parameters

- `key`: The key of an attribute. You can get this attribute by key. See [GetExtraAttribute\(\)](#).
- `value`: The value of the attribute.

3.3.4 AddExtraAttribute

```
bool cnstream::CNInferObject::AddExtraAttribute(const std::vector<std::pair<std::string,
                                                                    std::string>> &attributes)
```

Adds the key pairs of the extended attributes to a specified object.

Return Returns true if the attribute has been added successfully. Returns false if the attribute already exists.

Note This is a thread-safe function.

Parameters

- `attributes`: Attributes to be added.

3.3.5 AddFeature

`void cnstream::CNInferObject::AddFeature(const CNInferFeature &features)`

Adds the feature value to a specified object.

Return Void.

Note This is a thread-safe function.

Parameters

- `features`: The feature value you want to add to.

3.3.6 CNGetPlanes

`int cnstream::CNGetPlanes(CNDataFormat fmt)`

Gets image plane number by a specified image format.

Return

Parameters

- `fmt`: The format of the image.

Return Value

- 0: Unsupported image format.
- >0: Image plane number.

3.3.7 CopyToSharedMem

`void cnstream::CNDataFrame::CopyToSharedMem(MemMapType type)`

Copy source-data to shared memory, for multi-process case.

Return void.

Parameters

- `memory`: map/shared type.

3.3.8 CopyToSyncMem

`void cnstream::CNDataFrame::CopyToSyncMem()`

Synchronizes the source-data to [CNSyncedMemory](#).

3.3.9 Create

```
static std::shared_ptr<CNFrameInfo> cnstream::CNFrameInfo::Create(const std::string
                                                                    &stream_id, bool
                                                                    eos = false)
```

Creates a [CNFrameInfo](#) instance.

Return Returns `shared_ptr` of [CNFrameInfo](#) if this function has run successfully. Otherwise, returns NULL.

Parameters

- `stream_id`: The data stream alias. Identifies which data stream the frame data comes from.
- `eos`: If true, `CNDataFrame::flags` will be set to `CN_FRAME_FLAG_EOS`. Then, the modules do not have permission to process this frame. This frame should be handed over to the pipeline for processing.

3.3.10 GetAttribute

`CNInferAttr cnstream::CNInferObject::GetAttribute(const std::string &key)`

Gets an attribute by key.

Return Returns the attribute key. If the attribute does not exist, `CNInferAttr::id` will be set to -1.

Note This is a thread-safe function.

Parameters

- `key`: The key of an attribute you want to query. See `AddAttribute()`.

3.3.11 GetBytes

`size_t cnstream::CNDataFrame::GetBytes() const`

Gets the number of bytes in a frame.

Return Returns the number of bytes in a frame.

3.3.12 GetExtraAttribute

`std::string cnstream::CNInferObject::GetExtraAttribute(const std::string &key)`

Gets the extended attribute by key.

Return Returns the attribute that is identified by the key. If the attribute does not exist, returns NULL.

Note This is a thread-safe function.

Parameters

- `key`: The key of an identified attribute. See `AddExtraAttribute()`.

3.3.13 GetFeatures

`std::vector<CNInferFeature> cnstream::CNInferObject::GetFeatures()`

Gets the features of an object.

Return Returns the features of an object.

Note This is a thread-safe function.

3.3.14 GetMediaImage

`virtual void *cnstream::ICNMediaImageMapper::GetMediaImage() = 0`

Gets an image.

Return Returns the image address.

3.3.15 GetPlanes

```
int cnstream::CNDataFrame::GetPlanes() const
```

Gets plane count for a specified frame.

Return Returns the plane count of this frame.

3.3.16 GetPlaneBytes

```
size_t cnstream::CNDataFrame::GetPlaneBytes(int plane_idx) const
```

Gets the number of bytes in a specified plane.

Return Returns the number of bytes in the plane.

Parameters

- `plane_idx`: The index of the plane. The index increments from 0.

3.3.17 ImageBGR

```
cv::Mat *cnstream::CNDataFrame::ImageBGR()
```

Converts data from RGB to BGR. Called after [CopyToSyncMem\(\)](#) is invoked.

If data is not RGB image but BGR, YUV420NV12 or YUV420NV21 image, its color mode will not be converted.

Return Returns data with opencv mat type.

3.3.18 ~ICNMediaImageMapper

```
virtual cnstream::ICNMediaImageMapper::~~ICNMediaImageMapper()
```

Destructor of class `ICNMediaImageMapper`.

3.3.19 MmapSharedMem

```
void cnstream::CNDataFrame::MmapSharedMem(MemMapType type)
```

Map shared memory, for multi-process case.

Return void.

Parameters

- `memory`: map/shared type.

3.3.20 ReleaseSharedMem

```
void cnstream::CNDataFrame::ReleaseSharedMem(MemMapType type)
```

Release shared memery, for multi-process case.

Return void.

Parameters

- `memory`: map/shared type.

3.3.21 UnMapSharedMem

`void cnstream::CNDataFram::UnMapSharedMem(MemMapType type)`

Unmap shared memory, for multi-process case.

Return void.

Parameters

- `memory`: map/shared type.

3.4 Inferencer**3.4.1 CheckParamSet**

`bool cnstream::Inferencer::CheckParamSet(const ModuleParamSet ¶mSet) const`

Checks parameters for a module.

Return Returns true if this function has run successfully. Otherwise, returns false.

Parameters

- `paramSet`: Parameters of this module.

3.4.2 Close

`void cnstream::Inferencer::Close()`

Called by pipeline when the pipeline is stopped.

Return Void.

3.4.3 Open

`bool cnstream::Inferencer::Open(ModuleParamSet paramSet)`

Called by pipeline when the pipeline is started.

Return Returns true if the inferencer has been opened successfully.

Parameters

- `paramSet`:
 - `model_path`: The path of the offline model.
 - `func_name`: The function name that is defined in the offline model. It could be found in Cambricon twins file. For most cases, it is * "subnet0" .
 - `postproc_name`: The class name for postprocessing. See `cnstream::Postproc`.
 - `preproc_name`: The class name for preprocessing on CPU. See `cnstream::Preproc`.
 - `device_id`: MLU device ordinal number.
 - `batch_size`: The batch size. The maximum value is 32. The default value is 1. Only active on MLU100.

- `batching_timeout`: The batching timeout. The default value is 3000.0[ms].
type[float]. unit[ms].

3.4.4 Process

`int cnstream::Inferencer::Process(CNFrameInfoPtr data)`

Performs inference for each frame.

Parameters

- `data`: The information and data of frames.

Return Value

- 1: The process has run successfully.
- -1: The process is failed.

3.5 Module

3.5.1 CheckParamSet

`virtual bool cnstream::Module::CheckParamSet(const ModuleParamSet ¶mSet) const`

Checks parameters for a module, including parameter name, type, value, validity, and so on.

Return Returns true if this function has run successfully. Otherwise, returns false.

Parameters

- `paramSet`: Parameters for this module.

3.5.2 CheckPath

`bool cnstream::ParametersChecker::CheckPath(const std::string &path, const ModuleParamSet ¶mSet)`

Checks if the path exists.

Return Returns true if exists. Otherwise, returns false.

Parameters

- `path`: The path relative to JSON file or an absolute path.
- `paramSet`: The module parameters. The JSON file path is one of the parameters.

3.5.3 Close

`void cnstream::DataSource::Close()`

Called by pipeline when the pipeline is stopped.

3.5.4 Create

`Module* cnstream::ModuleFactory::Create(const std::string &strTypeName, const std::string &name)`

Creates a module instance with `ModuleClassName` and `moduleName`.

Return Returns the module instance if this function has run successfully. Otherwise, returns `nullptr` if failed.

Parameters

- `strTypeName`: The module class name.
- `name`: The `CreateFunction` of a `Module` object that has a parameter `moduleName`.

3.5.5 Create

`Module` *`cnstream::ModuleCreatorWorker::Create(const std::string &strTypeName, const std::string &name)`

Creates a module instance with `ModuleClassName` and `moduleName`.

Return Returns the module instance if the module instance is created successfully. Returns `nullptr` if failed.

See `ModuleFactory::Create`

Parameters

- `strTypeName`: The module class name.
- `name`: The module name.

3.5.6 CreateObject

`static T` *`cnstream::ModuleCreator::CreateObject(const std::string &name)`

Creates an instance of template (T) with sepcified instance name.

This is a template function.

Return Returns the instance of template (T).

Parameters

- `name`: The name of the instance.

3.5.7 ClearPerfManagers

`void cnstream::Module::ClearPerfManagers()`

Clear PerfManagers.

Return Void.

3.5.8 DoProcess

`int cnstream::Module::DoProcess(std::shared_ptr<CNFrameInfo> data)`

Processes the data.

This function is called by pipeline.

Return

Parameters

- `data`: The pointer to the information of the frame.

Return Value

- 0: The process has been run successfully. But the data should be transmitted by framework then.
- >0: The process has been run successfully. The data has been handled by this module. The `hasTransmit_` must be set. The `Pipeline::ProvideData` should be called by `Module` to transmit data to the next modules in the pipeline.
- <0: `Pipeline` posts an event with the `EVENT_ERROR` event type and return number.

3.5.9 GetModuleDesc

`std::string cnstream::Module::ParamRegister::GetModuleDesc()`

Gets the description of the module.

This is used in CNStream Inspect tool.

Return Returns the description of the module.

3.5.10 GetName

`std::string cnstream::Module::GetName() const`

Gets the name of this module.

Return Returns the name of this module.

3.5.11 GetOutputFrame

`std::shared_ptr<CNFrameInfo> cnstream::Module::GetOutputFrame()`

3.5.12 GetParams

`std::vector<std::pair<std::string, std::string>> cnstream::Module::ParamRegister::GetParams()`

Gets the registered parameters and the parameter descriptions.

This is used in CNStream Inspect tool.

Return Returns the registered parameters and the parameter descriptions.

3.5.13 GetPathRelativeToTheJSONFile

`std::string cnstream::GetPathRelativeToTheJSONFile(const std::string &path, const ModuleParamSet ¶m_set)`

Gets the complete path of a file.

If the path you set is an absolute path, returns the absolute path. If the path you set is a relative path, returns the path that appends the relative path to the specified JSON file path.

Return Returns the complete path of a file.

Parameters

- `path`: The path relative to the JSON file or an absolute path.
- `param_set`: The module parameters. The JSON file path is one of the parameters.

3.5.14 GetPerfManager

```
std::shared_ptr<PerfManager> cnstream::Module::GetPerfManager(const std::string
                                                           &stream_id)
```

Get `PerfManager` by stream id.

Return `PerfManager` pointer.

Parameters

- `stream_id`: stream id.

3.5.15 GetRegistered

```
std::vector<std::string> cnstream::ModuleFactory::GetRegistered()
```

Gets all registered modules.

Return All registered module class names.

3.5.16 HasTransmit

```
bool cnstream::Module::HasTransmit() const
```

Checks if this module has permission to transmit data by itself.

Return Returns true if this module has permission to transmit data by itself. Otherwise, returns false.

See [Process](#)

3.5.17 Instance

```
static ModuleFactory *cnstream::ModuleFactory::Instance()
```

Creates or gets the instance of the `ModuleFactory` class.

Return Returns the instance of the `ModuleFactory` class.

3.5.18 IsNum

```
bool cnstream::ParametersChecker::IsNum(const std::list<std::string> &check_list, const
                                         ModuleParamSet &paramSet, std::string
                                         &err_msg, bool greater_than_zero = false)
```

Checks if the parameters are number, and the value is specified in the correct range.

Return Returns true if the parameters are number and the value is in the correct range. Otherwise, returns false.

Parameters

- `check_list`: A list of parameter names.
- `paramSet`: The module parameters.
- `err_msg`: The error message.
- `greater_than_zero`: If this parameter is set to `true`, the parameter set should be greater than or equal to zero. If this parameter is set to `false`, the parameter set is less than zero.

3.5.19 IsRegistered

```
bool cnstream::Module::ParamRegister::IsRegistered(const std::string &key) const
```

Checks if the paramter is registered.

This is used in CNStream Inspect tool.

Return Returns true if the parameter has been registered. Otherwise, returns false.

Parameters

- key: The parameter name.

3.5.20 Open

```
virtual bool cnstream::Module::Open(ModuleParamSet param_set) = 0
```

Opens resources for a module.

Return Returns true if this function has run successfully. Otherwise, returns false.

Note You do not need to call this function by yourself. This function is called by pipeline automatically when pipeline is started. The pipeline calls the `Process` function of this module automatically after the `Open` function is done.

Parameters

- param_set: A set of parameters for this module.

3.5.21 PostEvent

```
bool cnstream::Module::PostEvent(EventType type, const std::string &msg) const
```

Posts an event to the pipeline.

Return Returns true if this function has run successfully. Returns false if this module is not added to the pipeline.

Parameters

- type: The type of an event.
- msg: The event message string.

3.5.22 Process

```
virtual int cnstream::Module::Process(std::shared_ptr<CNFrameInfo> data) = 0
```

Processes data.

Parameters

- data: The data to be processed by the module.

Return Value

- 0: The data is processed successfully. But the data should be transmitted in framework then.
- >0: The data is processed successfully. The data has been handled by this module. The `hasTransmit_` must be set. The `Pipeline::ProvideData` should be called by `Module` to transmit data to the next modules in the pipeline.
- <0: `Pipeline` will post an event with the `EVENT_ERROR` event type and return number.

3.5.23 Regist

```
bool cnstream::ModuleFactory::Regist(const std::string &strTypeName,
                                     std::function<Module*> const strTypeDesc,
                                     > pFuncRegisters ModuleClassName and CreateFunction.
```

Return Returns true if this function has run successfully.

Parameters

- `strTypeName`: The module class name.
- `pFunc`: The `CreateFunction` of a `Module` object that has a parameter `moduleName`.

3.5.24 Register

```
void cnstream::Module::ParamRegister::Register(const std::string &key, const std::string
                                               &desc)
```

Registers a paramter and its description.

This is used in CNStream Inspect tool.

Return Void.

Parameters

- `key`: The parameter name.
- `desc`: The description of the paramter.

3.5.25 SetContainer

```
void cnstream::Module::SetContainer(Pipeline *container)
```

Sets a container to this module and identifies which pipeline the module is added to.

Note This function is called automatically by the pipeline after this module is added into the pipeline. You do not need to call this function by yourself.

Parameters

- `container`: the container of this module, which is a pipeline pointer.

3.5.26 SetModuleDesc

```
void cnstream::Module::ParamRegister::SetModuleDesc(const std::string &desc)
```

Sets the description of the module.

This is used in CNStream Inspect tool.

Return Void.

Parameters

- `desc`: The description of the module.

3.5.27 SetPerfManagers

```
void cnstream::Module::SetPerfManagers(const          std::unordered_map<std::string,
                                                std::shared_ptr<PerfManager>>
                                                &perf_managers)
```

Sets PerfManagers, therefore, the module could use PerfManagers.

Return Void.

Parameters

- `perf_managers`: PerfManagers is an `unordered_map`, the key of which is stream id, and the value of which is `shared_ptr` points to a [PerfManager](#)

3.5.28 ShowPerfInfo

```
bool cnstream::Module::ShowPerfInfo()
```

Checks if showing performance information is enabled.

Return Returns true if the performance information is displayed. Otherwise, returns false.

3.5.29 ShowPerfInfo

```
void cnstream::Module::ShowPerfInfo(bool enable)
```

Enable or disable showing performance information.

Return Void.

Parameters

- `enable`: If it is true, enable showing performance information, otherwise, disable.

3.5.30 TransmitData

```
bool cnstream::Module::TransmitData(std::shared_ptr<CNFrameInfo> data)
```

Transmits data to the following stages.

Valid when the module has permission to transmit data by itself.

Return Returns true if the data has been transmitted successfully. Otherwise, returns false.

Parameters

- `data`: The pointer to the information of the frame.

3.6 Per Calculator

3.6.1 CalcLatency

```
PerfStats cnstream::PerfCalculator::CalcLatency(std::shared_ptr<Sqlite> sql, std::string
                                                type, std::string start_key, std::string
                                                end_key)
```

Calculates latency.

Each time we call this function, it will calculate latency from the previous time to now. After that, it will update the performance statistics, store it and replace the previous time with now. Finally, return the performance statistics.

Return `PerfStats`, i.e., performance statistics.

Parameters

- `sql`: A shared pointer points to `Sqlite` which is a class for operating the database.
- `type`: The perf type.
- `start_key`: The index name of start time points in database.
- `end_key`: The index name of end time points in database.

3.6.2 CalcThroughput

```
PerfStats cnstream::PerfCalculator::CalcThroughput (std::shared_ptr<Sqlite> sql,
                                                    std::string type,      std::string
                                                    start_node, std::string end_node)
```

Calculates throughput.

$\text{throughput} = \text{frame count} / (\text{the maximum of the end time points} - \text{the minimum of the start time points})$

Return `PerfStats`, i.e., performance statistics.

Parameters

- `sql`: A shared pointer points to `Sqlite` which is a class for operating the database.
- `type`: The perf type.
- `start_key`: The index name of the start time points in database.
- `end_key`: The index name of the end time points in database.

3.6.3 PrintLatency

```
void cnstream::PrintLatency(const PerfStats &stats)
```

Prints latency.

Return Void.

Parameters

- `stats`: Performance statistics.

3.6.4 PrintPerfStats

```
void cnstream::PrintPerfStats(const PerfStats &stats)
```

Prints performance statistics.

Return Void.

Parameters

- `stats`: Performance statistics.

3.6.5 PrintThroughput

void cnstream::PrintThroughput(const PerfStats &stats)

Prints throughput.

Return Void.

Parameters

- stats: Performance statistics.

3.7 Perf Manager

3.7.1 CalculatePerfStats

void cnstream::Pipeline::CalculatePerfStats()

Calculates performance of modules and pipeline, and prints performance statistics, every 2s.

This is a thread function.

Return Void.

3.7.2 CalculatePipelinePerfStats

std::vector<std::pair<std::string, PerfStats>> cnstream::PerfManager::CalculatePipelinePerfStats(std::string perf_type)

Calculates Performance statistics of pipeline.

Return Returns performance statistics of all end nodes of pipeline.

Parameters

- perf_type: The perf type.

3.7.3 Init

bool cnstream::PerfManager::Init(std::string db_name, std::vector<std::string> module_names, std::string start_node, std::vector<std::string> end_nodes)

Inits PerfManager.

Creates database and tables, create PerfCalculator, and start thread function, which is used to insert PerfInfo to database.

Return Returns true if PerfManager inits successfully, otherwise returns false.

Parameters

- db_name: The name of the database.
- module_names: All module names of the pipeline.
- start_node: Start node module name of the pipeline.
- end_nodes: All end node module names of the pipeline.

3.7.4 RecordPerfInfo

`bool cnstream::PerfManager::RecordPerfInfo(PerfInfo info)`

Records `PerfInfo`.

Creates timestamp and sets it to `PerfInfo`. And then inserts it to database.

Return Returns true if the info is recorded successfully, otherwise returns false.

Parameters

- `info`: `PerfInfo`.

3.7.5 RegisterPerfType

`bool cnstream::PerfManager::RegisterPerfType(std::string type)`

Registers perf type.

Return Returns true if type is registered successfully, otherwise returns false.

Parameters

- `type`: The perf type.

3.7.6 SqlBeginTrans

`void cnstream::PerfManager::SqlBeginTrans()`

Begins sqlite3 event.

Return Void.

3.7.7 SqlCommitTrans

`void cnstream::PerfManager::SqlCommitTrans()`

Commits sqlite3 event.

Return Void.

3.7.8 Stop

`void cnstream::PerfManager::Stop()`

Stops to record `PerfInfo`.

Return Void.

3.8 Pipelines

3.8.1 AddModule

`bool cnstream::Pipeline::AddModule(std::shared_ptr<Module> module)`

Adds the module to a pipeline.

Return Returns true if this function has run successfully. Returns false if the module has been added to this pipeline.

Parameters

- `module`: The module instance to be added to this pipeline.

3.8.2 AddModuleConfig

```
int cnstream::Pipeline::AddModuleConfig(const CNModuleConfig &config)
```

Adds module configurations in a pipeline.

Return Returns 0 if this function has run successfully. Otherwise, returns -1.

Parameters

- `The`: configuration of a module.

3.8.3 BuildPipeline

```
int cnstream::Pipeline::BuildPipeline(const std::vector<CNModuleConfig> &configs)
```

Builds a pipeline by module configurations.

Return Returns 0 if this function has run successfully. Otherwise, returns -1.

Parameters

- `configs`: The configurations of a module.

3.8.4 BuildPipelineByJSONFile

```
int cnstream::Pipeline::BuildPipelineByJSONFile(const std::string &config_file)
```

Builds a pipeline from a JSON file.

```
{
  "source" : {
    "class_name" : "cnstream::DataSource",
    "parallelism" : 0,
    "next_modules" : ["detector"],
    "custom_params" : {
      "source_type" : "ffmpeg",
      "decoder_type" : "mlu",
      "device_id" : 0
    }
  },
  "detector" : {...}
}
```

Return Returns 0 if this function has run successfully. Otherwise, returns -1.

Parameters

- `config_file`: The configuration file in JSON format.

3.8.5 CalculateModulePerfStats

```
void cnstream::Pipeline::CalculateModulePerfStats()
```

Calculates performance of modules and prints performance statistics.

This is called by thread function CalculatePerfStats.

Return Void.

3.8.6 CalculatePerfStats

```
void cnstream::Pipeline::CalculatePerfStats()
```

Calculates performance of modules and pipeline, and prints performance statistics, every 2s.

This is a thread function.

Return Void.

3.8.7 CalculatePipelinePerfStats

```
void cnstream::Pipeline::CalculatePipelinePerfStats()
```

Calculates performance of pipeline and prints performance statistics.

This is called by thread function CalculatePerfStats.

Return Void.

3.8.8 Close

```
void cnstream::Pipeline::Close()
```

See Module::Close.

3.8.9 CreatePerfManager

```
bool cnstream::Pipeline::CreatePerfManager(std::vector<std::string>      stream_ids,  
                                           std::string db_dir)
```

Creates [PerfManager](#) to measure performance of modules and pipeline, for each stream.

This function will create database for each stream. And two other threads will be created and start. One thread is for committing sqlite events to increase the speed of inserting data to the database. Another is for calculating performance of modules and pipeline, and printing performance statistics afterwards.

Return Returns true, if successfully create [PerfManager](#). Otherwise false.

Parameters

- `stream_ids`: The stream ids
- `db_dir`: The directory where database files will be saved

3.8.10 GetEventBus

`EventBus *cnstream::Pipeline::GetEventBus() const`

Gets the event bus in the pipeline.

Return Returns the event bus.

3.8.11 GetLinkIds

`std::vector<std::string> cnstream::Pipeline::GetLinkIds()`

Gets link-indexes that is used to query link status between modules. The link-index is the return value of `Pipeline::LinkModules`.

Return Returns all link-indexes in a pipeline.

See `Pipeline::LinkModules` and `Pipeline::QueryLinkStatus`.

3.8.12 GetModule

`Module *cnstream::Pipeline::GetModule(const std::string &moduleName)`

Gets a module in a pipeline by name.

Return Returns the module pointer if the module named `moduleName` has been added to the pipeline. Otherwise, returns `nullptr`.

Parameters

- `moduleName`: The module name specified in the module constructor.

3.8.13 GetModuleConfig

`CNModuleConfig cnstream::Pipeline::GetModuleConfig(const std::string &module_name)`

Gets the module configuration by the module name.

Return Returns module configuration if this function has run successfully. Returns `NULL` if the module specified by `module_name` has not been added to this pipeline.

Parameters

- `module_name`: The module name specified in module constructor.

3.8.14 GetModuleParallelism

`uint32_t cnstream::Pipeline::GetModuleParallelism(std::shared_ptr<Module> module)`

Gets the module parallelism.

Return Returns the module parallelism if this function has run successfully. Returns 0 if the module has not been added to this pipeline.

Parameters

- `module`: The module you want to query.

3.8.15 GetModuleParamSet

`ModuleParamSet` `cnstream::Pipeline::GetModuleParamSet(const std::string &moduleName)`

Gets parameter set of a module. `Module` parameter set is used in `Module::Open`. It provides the ability for modules to customize parameters.

Return Returns the customized parameters of the module. If the module does not have customized parameters or the module has not been added to this pipeline, then the value of `size (ModuleParamSet::size)` is 0.

See `Module::Open`.

Parameters

- `moduleName`: The module name specified in the module constructor.

3.8.16 GetStreamMsgObserver

`StreamMsgObserver *` `cnstream::Pipeline::GetStreamMsgObserver()` `const`

Gets the stream message observer that has been bound with this pipeline.

Return Returns the stream message observer that has been bound with this pipeline.

See `Pipeline::SetStreamMsgObserver`.

3.8.17 IsRunning

`bool` `cnstream::Pipeline::IsRunning()` `const`

Returns the running status for a pipeline.

Return Returns true if the pipeline is running. Returns false if the pipeline is not running.

3.8.18 LinkModules

`std::string` `cnstream::Pipeline::LinkModules(std::shared_ptr<Module> up_node, std::shared_ptr<Module> down_node)`

Links two modules. The upstream node will process data before the downstream node.

Return Returns the link-index if this function has run successfully. The link-index can be used to query link status between `up_node` and `down_node`. See `Pipeline::QueryStatus` for details. Returns NULL if one of the two nodes has not been added to this pipeline.

Note Both `up_node` and `down_node` should be added to this pipeline before calling this function.

See `Pipeline::QueryStatus`.

Parameters

- `up_node`: The upstream module.
- `down_node`: The downstream module.

3.8.19 NotifyStreamMsg

void cnstream::Pipeline::NotifyStreamMsg(const StreamMsg &smmsg)

Passes the stream message to the observer of this pipeline.

Return Void.

See StreamMsg.

Parameters

- smmsg: The stream message.

3.8.20 Open

bool cnstream::Pipeline::Open(ModuleParamSet paramSet)

See Module::Open.

3.8.21 ParseByJSONFile

bool cnstream::CNModuleConfig::ParseByJSONFile(const std::string &jfname)

Parses members from JSON file except CNModuleConfig::name.

Return Returns true if the JSON file has been parsed successfully. Otherwise, returns false.

3.8.22 ParseByJSONStr

bool cnstream::CNModuleConfig::ParseByJSONStr(const std::string &jstr)

Parses members from JSON string except CNModuleConfig::name.

Return Returns true if the JSON file has been parsed successfully. Otherwise, returns false.

3.8.23 PerfSqlCommitLoop

void cnstream::Pipeline::PerfSqlCommitLoop()

Commits sqlite events to increase the speed of inserting data to the database.

This is a thread function. It will commit events every one second.

Return Void.

3.8.24 Process

int cnstream::Pipeline::Process(std::shared_ptr<CNFrameInfo> data)

Useless.

See Module::Process.

3.8.25 ProvideData

```
bool cnstream::Pipeline::ProvideData(const Module *module,
                                     std::shared_ptr<CNFrameInfo> data)
Provides data for this pipeline that is used in source module or the module transmission by itself.
```

Return Returns true if this function has run successfully. Returns false if the module is not added in the pipeline or the pipeline has been stopped.

See [Module::Process](#).

Parameters

- `module`: The module that provides data.
- `data`: The data that is transmitted to the pipeline.

3.8.26 QueryLinkStatus

```
bool cnstream::Pipeline::QueryLinkStatus(LinkStatus *status, const std::string &link_id)
Queries the link status by link-index. link-index is returned by Pipeline::LinkModules.
```

Return Returns true if this function has run successfully. Otherwise, returns false.

See [Pipeline::LinkModules](#).

Parameters

- `status`: The link status to query.
- `link_id`: The Link-index returned by [Pipeline::LinkModules](#).

3.8.27 RegistIPCFrameDoneCallBack

```
void cnstream::Pipeline::RegistIPCFrameDoneCallBack(std::function<void>std::shared_ptr<CNFrameInfo>
> callback)
Regist IPC frame done callback function.
```

Return Void.

3.8.28 SetModuleAttribute

```
bool cnstream::Pipeline::SetModuleAttribute(std::shared_ptr<Module> module, uint32_t
                                           parallelism, size_t queue_capacity = 20)
Sets the parallelism and conveyor capacity attributes of the module.
```

The `SetModuleParallelism` function is deprecated. Please use the `SetModuleAttribute` function instead.

Return Returns true if this function has run successfully. Returns false if this module has not been added to this pipeline.

Note You must call this function before calling [Pipeline::Start](#).

See [CNModuleConfig::parallelism](#).

Parameters

- `module`: The module to be configured.
- `parallelism`: [Module](#) parallelism, as well as [Module](#)' s conveyor number of input connector.

- `queue_capacity`: The queue capacity of the `Module` input conveyor.

3.8.29 SetStreamMsgObserver

`void cnstream::Pipeline::SetStreamMsgObserver(StreamMsgObserver *observer)`

Binds the stream message observer with this pipeline to receive stream message from this pipeline.

Return Void.

See `StreamMsgObserver`.

Parameters

- `observer`: The stream message observer.

3.8.30 Start

`bool cnstream::Pipeline::Start()`

Starts a pipeline. Starts data transmission in a pipeline. Calls the `Open` function for all modules. See `Module::Open`. Links modules.

Return Returns true if this function has run successfully. Returns false if the `Open` function did not run successfully in one of the modules, or the link modules failed.

3.8.31 Stop

`bool cnstream::Pipeline::Stop()`

Stops data transmissions in a pipeline.

Return Returns true if this function has run successfully. Otherwise, returns false.

3.9 Syncmem

3.9.1 CNStreamFreeHost

`void cnstream::CNStreamFreeHost(void *ptr)`

Frees the data allocated by `CNStreamMallocHost`.

Parameters

- `ptr`: The data address to be freed.

3.9.2 CNStreamMallocHost

`void cnstream::CNStreamMallocHost(void **ptr, size_t size)`

Allocates data on a host.

Parameters

- `ptr`: Outputs data pointer.
- `size`: Size of the data to be allocated.

3.9.3 CNSyncedMemory

`cnstream::CNSyncedMemory::CNSyncedMemory(size_t size)`
 Constructor.

Parameters

- `size`: The size of the memory.

3.9.4 CNSyncedMemory

`cnstream::CNSyncedMemory::CNSyncedMemory(size_t size, int mlu_dev_id, int mlu_ddr_chn)`
 Constructor.

Parameters

- `size`: The size of the memory.
- `mlu_dev_id`: MLU device ID that is incremented from 0.
- `mlu_ddr_chn`: The MLU DDR channel that is greater than or equal to 0, and is less than 4. It specifies which piece of DDR channel the memory allocated on.

3.9.5 GetCpuData

`const Void *cnstream::CNSyncedMemory::GetCpuData()`
 Gets the CPU data.

Return Returns the CPU data pointer.

Note If the size is 0, always returns nullptr.

3.9.6 GetHead

`SyncedHead cnstream::CNSyncedMemory::GetHead() const`
 Gets synchronized head.

Return Returns synchronized head.

3.9.7 GetMluData

`const Void *cnstream::CNSyncedMemory::GetMluData()`
 Gets the MLU data.

Return Returns the MLU data pointer.

Note If the size is 0, always returns nullptr.

3.9.8 GetMluDdrChnId

`int cnstream::CNSyncedMemory::GetMluDdrChnId() const`
 Gets the channel ID of the MLU DDR.

Return Returns the DDR channel ID that the MLU memory allocated on.

3.9.9 GetMluDevId

```
int cnstream::CNSyncedMemory::GetMluDevId() const
```

Gets the MLU device ID.

Return Returns the device that the MLU memory allocated on.

3.9.10 GetMutableCpuData

```
void *cnstream::CNSyncedMemory::GetMutableCpuData()
```

Gets the mutable CPU data.

Return Returns the CPU data pointer.

3.9.11 GetMutableMluData

```
void *cnstream::CNSyncedMemory::GetMutableMluData()
```

Gets the mutable MLU data.

Return Returns the MLU data pointer.

3.9.12 GetSize

```
size_t cnstream::CNSyncedMemory::GetSize() const
```

Gets data bytes.

Return Returns data bytes.

3.9.13 SetCpuData

```
void cnstream::CNSyncedMemory::SetCpuData(void *data)
```

Sets the CPU data.

Return Void.

Parameters

- data: The data pointer on CPU.

3.9.14 SetMluCpuData

```
void cnstream::CNSyncedMemory::SetMluCpuData(void *mlu_data, void *cpu_data)
```

Sets the MLU data and the CPU data.

Return Void.

Parameters

- mlu_data: The data pointer on MLU.
- cpu_data: The data pointer on CPU.

3.9.15 SetMluData

```
void cnstream::CNSyncedMemory::SetMluData(void *data)
```

Sets the MLU data.

Parameters

- data: The data pointer on MLU.

3.9.16 SetMluDevContext

```
void cnstream::CNSyncedMemory::SetMluDevContext(int dev_id, int ddr_chn = 0)
```

Sets the MLU device context.

Note You need to call this API before all getters and setters.

Parameters

- dev_id: The MLU device ID that is incremented from 0.
- ddr_chn: The MLU DDR channel ID that is greater than or equal to 0, and less than 1. It specifies which piece of DDR channel the memory allocated on.

3.9.17 ToCpu

```
void cnstream::CNSyncedMemory::ToCpu()
```

Synchronizes the memory data to CPU.

3.9.18 ToMlu

```
void cnstream::CNSyncedMemory::ToMlu()
```

Synchronizes the memory data to MLU.

3.10 Tracker

3.10.1 CheckParamSet

```
bool cnstream::Tracker::CheckParamSet(const ModuleParamSet &paramSet) const
```

Checks parameters for a module.

Return Returns true if this function has run successfully. Otherwise, returns false.

Parameters

- paramSet: Parameters for this module.

3.10.2 Close

```
void cnstream::Tracker::Close()
```

Called by pipeline when pipeline is stopped.

Return None.

Parameters

- None.:

3.10.3 Open

`bool cnstream::Tracker::Open(cnstream::ModuleParamSet paramSet)`

Called by pipeline when pipeline is started.

Return Returns if the module has been opened successfully.

Parameters

- paramSet:
 - track_name: The class name for track. The “FeatureMatch” is provided.
 - model_path: The path of the offline model.
 - func_name: Function name defined in the offline model. This can be found in the Cambricon twins description file. It is “subnet0” for the most cases.

3.10.4 Process

`int cnstream::Tracker::Process(std::shared_ptr<CNFrameInfo> data)`

Processes each frame.

Return Whether the process succeed.

Parameters

- data: : Pointer to the frame information.

Return Value

- 0: The process has run successfully and does no intercept data.
- <0: The process is failed.



4 Release Notes

This release notes outlines CNStream API updates and documentation updates in CNStream Developer Guide.

4.1 Release 2020-04-16 (Version 4.4.0)

4.1.1 API Updates

This section lists API functions and fields that were added, changed, or removed.

- The following APIs are supported in Frame module for multi-process function:
 - Added the new `MmapSharedMem` API to map shared memory.
 - Added the new `UnMapSharedMem` API to unmap shared memory.
 - Added the new `CopyToSharedMem` API to copy source-data to shared memory.
 - Added the new `ReleaseSharedMem` API to release shared memory.
- The following APIs are supported in Module module for the performance measurement function:
 - Added the new `SetPerfManagers` API to set PerfManagers.
 - Added the new `GetPerfManager` API to retrieve PerfManager by stream id.
 - Added the new `ClearPerfManagers` API to clear PerfManagers.
- The following APIs are supported in Pipeline module for the performance measurement function:
 - Added the new `CreatePerfManager` API to create PerfManager for each stream to measure performance of modules and pipeline.
 - Added the new `PerfSqlCommitLoop` API to commit sqlite events to increase the speed of inserting data to the database.
 - Added the new `CalculatePerfStats` API to calculate performance of modules and pipeline, and print performance statistics.
 - Added the new `CalculateModulePerfStats` API to calculate performance of modules, and print performance statistics.
 - Added the new `CalculatePipelinePerfStats` API to calculate performance of pipeline, and print performance statistics.
 - Removed the `PrintPerformanceInformation` API due to function changes.

4.1.2 Doc Updates

This section lists the documentation updates that were made in this version:

- Optimized the description of the APIs.
- Added the missing description of APIs and datatypes.

4.2 Release 2020-02-24

4.2.1 API Updates

This section lists API functions and fields that were added, changed, or removed.

- The following APIs are supported in Frame module:
 - Supported the new virtual `GetMediaImage` API.
 - Supported the new virtual `GetPitch` API.
 - Supported the new virtual `GetCpuAddress` API.
 - Supported the new virtual `GetDevAddress` API.
 - Supported the new virtual `~ICNMediaImageMapper` API.
 - Parameter changes in `DevContext` struct.
- The following APIs are supported in Syncmem module:
 - Supported the new `SetMluCpuData` API to set the CPU and MLU data for MLU220SOC only.
 - Supported the new `mlu_data` and `cpu_data` parameters to the `SetMluCpuData` API.

4.3 Release 2019-12-31

4.3.1 API Updates

This section lists API functions and fields that were added, changed, or removed.

- The following APIs are supported in Module module:
 - Supported the new `IsRegistered` API for checking if a module parameter is registered or not.
 - Supported the new `SetModuleDesc` API for setting module description.
 - Supported the new `GetModuleDesc` API for getting module description.
 - Supported the new `CheckParamSet` API for checking ParamSet in a module.
 - Supported the new `GetRegistered` API for getting all registered modules name.
 - Supported the new `CheckPath` API for checking path of a configuration file.
 - Supported the new `IsNum` API for checking if a parameter is a number.
- The following APIs are supported in Inferencer module:
 - Supported the new `CheckParamSet` API for checking ParamSet in Inferencer module.
- The following APIs are supported in Data Source module:
 - Supported the new `CheckParamSet` API for checking ParamSet in DataSource module.
- The following APIs are supported in Tracker module:
 - Supported the new `CheckParamSet` API for checking ParamSet in Tracker module.